

POWER DUSTER SPRAY

„FLAMMABLE“




Provides quick and effective computer and electronic maintenance. Use for cleaning in hard-to-reach areas of keyboards, printers, scanners, copiers, optical drives, etc. Compact 100 ml version. You can reach every well-hidden bit of dirt and dust with the included extension straw.

Instructions of use Use and store at room temperature. Disconnect device from power supply and allow to cool first. Do not shake. Spray in short bursts on the surface to be treated. Use the extension straw for hard-to-reach areas. Use in upright position only. Recommended for computers, keyboards, sewing machines, copiers, telephones, lab equipment, TV's, vacuum cleaners, shredders, scanners, stereos, watches, clocks, mailing machines, fans, audio equipment, electric razors, sports equipment, musical instruments, guns, desk tops, camera equipment. Use the extension straw for hard-to-reach areas.

Technical info

CONTENT 100 ml



Logistic info:

FP# (export)	can dimension & type	pcs/box	pcs/pallet (export)	weight/box	weight/pallet (export)
FP004564	Sticker label	24	3.840 pcs	-	426,40 kg